



NOTES:

1. IB EDGE METAL TO BE FASTENED WITH RING SHANK NAILS AT 4" O.C. STAGGERED OR WITH IB FASTENERS AT 12" O.C.
2. FOR BEST RESULTS, PROVIDE 1/4" SPACE AT METAL JOINTS, SECURE EACH SIDE WITH TWO FASTENERS, COVER JOINT ALONG DECK FLANGE AND FASCIA WITH 2" WIDE FOIL TAPE, INSTALL IB NR 5" X 8" METAL JOINT PATCH CENTERED OVER THE JOINT AND INSTALL FIELD MEMBRANE.
3. PLANE OR ROUTER PLYWOOD DECK TO ACHIEVE SUFFICIENT RECESSED AREA.

Scale:
NTS

Detail Name:

Clad Drip Edge - Routed

Detail Number:

DS-02

Submitted By:
Address:
Telephone:

Project:
Address: