



Product Description:

IB TPO SA Yellow Safety Tape is made from 30 mil non-reinforced thermoplastic polyolefin, (TPO) membrane laminated to a 25-mil thick, self-adhesive tape.

Use:

- Used as a visual and physical safety warning designation on roof areas including areas of caution and potential life safety hazards.
- Used in conjunction with IB TPO Primer

Thickness:

- 30 mil – membrane
- 25 mil – tape

Available Colors:



Sizes:

5.5" x 100' / 19 lbs.

Packaging:

Supplied in an individual roll

Application:

Refer to IB TPO Specifications and Construction Details for installation requirements and additional information for specific uses. Prior to application, use the IB TPO Cleaner to ensure no oil, dirt, moisture, or other contaminants that could adversely affect the adhesion. After the membrane has been cleaned, prepare to install IB TPO Primer to the membrane surface where the safety tape will be applied. Prepare the primer for application by mixing it thoroughly, stirring every 15-20 minutes during application. Note: After mixing, the product may develop a texture like applesauce. This is normal and does not affect performance. Once surfaces are dry, apply the IB TPO Primer using a brush or a scouring pad in a full and uniform application. Avoid overworking the primer. Let the primer dry completely, typically within 20 minutes, before applying the IB TPO SA Yellow Safety Tape. It should look dull or flat and feel dry to touch. Drying time may vary based on air temperature and humidity. Remove the release liner from the safety tape and slowly apply to the applied membrane working the tape into place to avoid wrinkles.



Product details stated are nominal as manufactured, and the results of tests and/or calculations and therefore are non-binding and do not represent a guarantee or warranted characteristics. User and/or designer are responsible for confirming suitable performance for specific application and conforming with all applicable laws and regulations.

Use a hand roller to ensure strong adhesion between the safety tape and the TPO membrane. Roll until all surfaces are smooth against the receiving substrates. Avoid installing IB TPO SA Yellow Safety Tape over membrane seams and membrane overlaps, if possible. Membranes must not be applied during adverse weather or without precautionary measures in temperatures below 40°F (4°C). All surfaces should be clean, dry, free of dirt, dust, debris, oils, soaps, coatings, and other contaminants that may inhibit bonding.

Storage:

Store IB TPO SA Yellow Safety Tape indoors, out of direct sunlight, in temperatures between 60°F – 80°F (16°C – 27°C) in original unopened containers and away from objects that could cause physical damage or create punctures as well as ignition sources. The membrane is flammable and will catch fire when exposed to open flame.

Self-Life:

18 months from date of manufacture

Safety Precautions:

Use proper equipment and assistance when moving, lifting, handling, or transporting membrane rolls to avoid personal injuries as well as damage to the membrane. Refer to the Product Safety Data Sheet for additional safety information.

Go to <https://ibroof.com/tds> for the most up-to-date version of this document.

Toll Free: 800-426-1626

Care has been taken to ensure that the contents of this publication are accurate, however IB Roof Systems and any subsidiary companies do not accept responsibility for errors or for information that is found to be misleading. Suggestions for, or description of, the end use of application of products or methods of working, are for information only and IB Roof systems and any subsidiary accept no responsibility in respect thereof.



Quality Products



Exceptional Service



Technical Expertise

IBroof.com

510910025 1/16/2026