



**NOTES:**

1. FASTENING PATTERNS ARE PROVIDED AS GUIDELINES FOR FASTENER PLACEMENT FOR MECHANICALLY ATTACHED INSULATION OR COVER BOARD UNDER AN ADHERED TPO MEMBRANE SYSTEM.
2. AN APPROVED COVER BOARD IS REQUIRED OVER EPS & XPS, & INSULATIONS NOT APPROVED BY IB ROOF SYSTEMS.
3. REFER TO TABLE A.2 FOR MINIMUM REQUIREMENTS FOR INSULATION FASTENER SCHEDULE FOR ADHERED IB TPO MEMBRANES.

<b>Scale:</b> NTS	<b>Detail Name:</b> <b>1 Per 2.3 Fastening Patterns for Insulation/Cover Board</b>	<b>Detail Number:</b> <b>FA-T-06</b>
<b>Submitted By:</b> Address: Telephone:		<b>Project:</b> Address: