



**NOTES:**

1. NON-CLAD EDGE METAL TO BE FASTENED WITH STAINLESS STEEL NAILS AT 4" O.C. STAGGERED OR WITH IB HD #14 FASTENERS AT 12" O.C.
2. SECURE FLASHINGS AND METAL WORK IN ACCORDANCE WITH IB SPECIFICATIONS AND FLASHING SECUREMENT TABLE.
3. CLEAN AND WIPE METAL EDGING PRIOR TO INSTALLATION.
4. IB TPO SA COVER TAPE, OR IB TPO HW-SA COVER TAPE AS APPLICABLE. SEE RELATED APPLICATION ON CLAD DRIP EDGE DETAIL.

<b>Scale:</b> NTS	<b>Detail Name:</b> <b>Drip Edge Profile for Non-Clad Metal</b>	<b>Detail Number:</b> <b>T-PE-19</b>
----------------------	--	---

<b>Submitted By:</b> Address: Telephone:	<b>Project:</b> Address:
--	-----------------------------