



**NOTES:**

1. SUMP AREAS AT DRAINS SHOULD BE FORMED INTO THE DECK OR INSTALLED WITH TAPERED INSULATION.
2. APPROVED DRAIN TYPES INCLUDE: CAST IRON, SPUN ALUMINUM, OR COPPER WITH CLAMPING RINGS.
3. MEMBRANE DRAIN LINERS ARE NOT ELIGIBLE FOR IB TOTAL ROOF SYSTEM WARRANTIES AND REQUIRE PRE-APPROVAL FOR USE ON IB WARRANTED PROJECTS.
4. RE-ROOF APPLICATIONS: AN APPROVED SEPARATION LAYER IS REQUIRED TO FULLY DIVORCE THE IB MEMBRANE FROM ANY EXISTING INCOMPATIBLE MATERIALS.
5. TARGET SHEETS CAN BE INSTALLED BEFORE OR AFTER FIELD MEMBRANE.

<b>Scale:</b> NTS	<b>Detail Name:</b> <b>IB TPO Overflow Drain Layout</b>	<b>Detail Number:</b> <b>T-RD-03</b>
----------------------	--	---

<b>Submitted By:</b> Address: Telephone:	<b>Project:</b> Address:
--	-----------------------------