



Product Description:

IB PVC Universal Pipe Flashing is a flexible injection molded PVC stepped-rib profile flashing with a preformed flange and is designed for easy installation to reduce roof top labor and call backs by reducing workmanship errors.

Use:

- For use around roof top penetrations such as pipe, conduit, gas lines, and other circular profile penetrations and flashings.
- Variable Size Options: May be cut to flash pipe penetrations 1" to 6" in diameter.
- The stepped-rib design allows for easy sizing in the field and ensures the included stainless-steel clamp remains securely in place, providing a more reliable and aesthetic solution than field fabrication.
- Note: IB PVC Universal Pipe Flashings are not intended to function as an exhaust vent or moisture relief vent.

Thickness:

60 mil

Available Colors:



White

Sizes:

Each flashing is approximately 8" in height and is designed to accommodate pipe diameters ranging from 1" to 6".

Packaging:

Each box contains ten (10) pipe flashings and metal clamps. Also sold individually.

Box weight = 8 lbs. Individual weight = 1.3 lbs.

** Standard size pipe clamps covering the largest possible range (6" diameter) are included for each pipe boot. Dimensions less than 1.5" (3.8 cm) diameter may require alternative clamps.*

Storage:

Store IB PVC Universal Pipe Flashing indoors, out of direct sunlight, in original unopened containers and away from objects that could cause physical damage or create punctures.

Safety Precautions:

Use proper equipment and assistance when moving, lifting, handling, or transporting membrane rolls to avoid personal injuries as well as damage to the membrane. Refer to the Product Safety Data Sheet for additional safety information.

Application:



Product details stated are nominal as manufactured, and the results of tests and/or calculations and therefore are non-binding and do not represent a guarantee or warranted characteristics. User and/or designer are responsible for confirming suitable performance for specific application and conforming with all applicable laws and regulations.

Refer to IB PVC Specifications and Construction Details for installation requirements and additional information for specific uses. Prior to application, use the IB Membrane Cleaner to ensure no oil, dirt, moisture, or other foreign materials are present on either the receiving substrate or the rooftop penetration that could damage the pipe flashing. Cut out a circle on the top of the pipe flashing that is narrower than the rooftop penetration and then slide it down over the penetration. Make sure the pipe flashing is snug around the penetration and sits well with the receiving substrate. Mark where the top of the pipe flashing will sit on the penetration once installed. Then, lift the pipe flashing up and apply a minimum ¼" bead application of the IB Water Stop Sealant around the penetration and slide the pipe boot back down over the Water Stop Sealant (no need to wait for sealant to skin over). This will create a watertight seal between the pipe boot and the penetration. Install the metal pipe clamp at the top of the pipe boot and tighten it to finish the seal. Heat-weld the flange of the pipe flashing to the PVC membrane to fuse them together. Use a roller to ensure a proper weld and probe for any locations that has not been fully welded in the seam area.

Refer to www.ibroof.com for additional installation instructions. Membranes must not be applied during adverse weather or without precautionary measures in temperatures below 40°F (4°C). All surfaces should be clean, dry, free of dirt, dust, debris, oils, soaps, coatings, and other contaminants that may inhibit bonding.

Go to <https://ibroof.com/tds> for the most up-to-date version of this document.

Toll Free: 800-426-1626

Care has been taken to ensure that the contents of this publication are accurate, however IB Roof Systems and any subsidiary companies do not accept responsibility for errors or for information that is found to be misleading. Suggestions for, or description of, the end use of application of products or methods of working, are for information only and IB Roof systems and any subsidiary accept no responsibility in respect thereof.