



NOTES:

1. IB FASTENERS & MEMBRANE PLATES INSTALLED 6" O.C. WITH A MINIMUM OF 3 FASTENERS FOR PIPES LESS THAN 12" IN DIAMETER (12" O.C. WITH MINIMUM OF 4 FASTENERS FOR PIPES GREATER THAN 12" DIAMETER).
2. SEALANTS AND CAULKING REQUIRE PERIODIC OWNER MAINTENANCE.
3. ROOF PENETRATIONS EXCEEDING 120°F, REFER TO THE IB HOT TPO PIPE FLASHING DETAIL.
4. CLEAN PENETRATION PRIOR TO FLASHING TO REMOVE ALL BITUMINOUS RESIDUE OR CONTAINMENTS, OR COVER WITH ALUMINUM FOIL TAPE.
5. EACH PIPE FLASHING IS DESIGNED TO ACCOMMODATE PIPE DIAMETERS RANGING FROM 1" TO 6". EACH BOOT HAS A CUTTING GUIDE, DIAMETER MEASUREMENTS, AND INCLUDES A METAL CLAMP.
6. IB TPO PIPE FLASHINGS ARE NOT TO BE USED OR FUNCTION AS AN EXHAUST VENT OR MOISTURE RELIEF VENT.

Scale: NTS	Detail Name: <h2 style="text-align: center;">IB TPO Pipe Flashing</h2>	Detail Number: <h2 style="text-align: center;">T-PS-02</h2>
----------------------	--	---

Submitted By: Address: Telephone:	Project: Address:
--	-----------------------------